

1) When you receive a call from other unit during talk, other unit's number is displayed.
 Press “#” button twice if you want to talk with other unit.
 Ex) when you receive a call from No.2 unit during talking with No.1, No.2 is displayed. Press “#” to end the talk with No.1 unit and start to talk with No.2 unit.

**** Public Notice function.(ALL CALL)**

1) It is to use to make a public notice from CM-810 to CM-800S.
 Ex) Press “0” and then “#” to open all the lines of CM-800S.

**** Setup for CM-810.(Master Unit)**

- 1) Choice of the ring type out of two.
- 2) Setup Ring-time duration
 - It is available to set ring-time when CM-810 receives a call from CM-800S (from 1 to 20 Seconds).
- 3) Setup Method. (Ring type and ring-time duration).
 - Setup mode : Hold “*” button for 2 seconds and release it in standby mode

■ Setup ring type out of two.

- “SD” sign and the number of unit in use blink in turn on the display when set-up mode is in.
- Select 1 or 2 from Ten Key and then “#” to move on to ring- duration setup mode with saving.
- Press “*” button to move on to ring duration setup mode without saving.

■ Setup ring-duration

- It is to setup the time of ring-duration of CM-810.
- “tE” sign and the number of CM-800S in use blinks in turn on the display.
- It is available to setup duration time from 1 to 20 seconds using ten- key.
- Press “#” button after enter the time.
- And then it becomes standby mode automatically.
- Press “*” button to be out without saving.
- ※ Wrong registration makes “beep” sound.

4-2 CM-800S (Sub-Unit)

- 1) Pressing the call button makes ring.
- 2) You can talk with CM-810 without any operation of CM-800S.
- 3) Pressing “privacy” button to stop delivering the voice from CM-800S to CM-810.

! Warning

Please don't disassemble, repair or rebuild this product arbitrarily (please contact the service center if a repair is needed). It may cause an electric shock or fire.    No disassembly Electric shock Fire	If an abnormal sound, burning smell or smoke is coming out of the product, please plug out the power cable and contact a service center. It may cause an electric shock or fire.   Electric shock Fire	Please don't insert any metallic or burnable materials into the ventilation hole. It may cause an electric shock or fire.    Prohibition Electric shock Fire	Please use only the designated batteries for the products of using DC power. It may cause an electric shock or fire.   Request
--	--	---	---

! Caution

Please plug the power cable firmly into the inner end. It may cause a fire.   Request Fire	Please hold the plug tightly when unplugging the power cable (a part of the copper wire may be disconnected if the grabbing is only made on the cord when pulling out the cable). It may cause an electric shock or fire.    Request Electric shock Fire	When connecting the power cables after cutting the cable, please install the product with power off. It may cause an electric shock or fire.    Request Electric shock Fire	When installing the product, please fix it firmly while using the wall-mounting unit and screws. It may cause an injury from the falling object.  Request
Please be careful when using an AC circuit breaker since there is a possibility of an electric shock.   Request Electric shock	Please check the use voltage and current for the DC-only products and use the appropriate rectifier. It may cause a fire.   Request Fire	Please avoid direct rays of the sun or heating devices at a time of installation. It may cause a fire.    Request Overheating Fire	Please don't install the product on an unstable place or small support board. It may cause an injury if it falls down while in use.  Request

Power & Installation

Cleaning & Use

When cleaning the product, please rub it with a soft and dry cloth after plugging out the power cable. (Please don't use any chemical products such as wax, benzene, alcohol or cleanser.)  Prohibition	Please don't drop the product on the ground and don't apply a shock. It may cause a failure.  Prohibition	Please use the designated connection cable within the maximum calling distance designated for the product. It may reduce the product performance.  Request
--	--	---