


■CAUTIONS

All the safety and operating instruction should be read before the appliance is operated and retained for future reference.

- The appliance should not be used near water-for example, near a bathtub, washbowl, kitchen sink, laundry/tub, in a wet basement, or near a swimming pool, etc.
- The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation opening; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
- The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliance that produce heat.
- Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

■CONTROLS AND FUNCTIONS



1. BUTTON
2. NAME PLATE
3. HOOK LEVER
4. VOLUME S/W
5. HAND SET
6. SPRING CORD
7. TERMINAL BOX

■OPERATION INSTRUCTIONS

1. Only one conversation can take place at any one time, but conferences between more than two stations are possible.
2. To call station, or stations, raise the handset (5) and check that no one else is using the system.
3. Depress the desired station buttons (1) this sends a call tone to the other stations.
4. when was the bell rings, raise the handset and speaking with the other party like telephone.
5. On completion of the conversation, replace the handset-this action automatically switches off the power.

NOTE: 1) Can control the sound by use volume switch (4) As example, you may setting on the volume switch at "L" position, volume is lower but setting at "H" position, volume is higher.

- 2) If you going to paging, press the button of its own No and talking to the microphone of this phone. At that time, not receive the paging broadcast if it be talking over the phone.

■FEATURES

1. Available the paging at any station.
2. Call signal is tremolo sound.
3. Control the volume signal by use switch.
4. Available to use both desk type and wall mounted.
5. Soft touch Numerical key, pad.