

Important Safeguards

14 Servicing - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

15 Replacement Parts - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or having the same characteristics as the original part.

16 Safety Check - Upon completion of service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

17 Power Line - The system should not be located near overhead power lines or other electric light or power circuits, or where it can fall into power lines or circuits.

18 Attachment - Do not use attachments not recommended by the product manufacturer as they may cause hazards.

19 Outdoor Cable Protection - All outdoor connections should be protected from moisture. Internal heating can draw moisture or condensation into the covering of the unit and affect its operation.

20 Lightning - For added protection for this product before a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges. Be sure to lightning and power-line surges. Be sure is properly grounded, as defined above. If you live in an area heavily prone to lightning storms, it is recommended that you invest in power-line, telephone-line, RF cable and Actuator/Polarization surge protectors to protect your system from possible damage.

Note to system installer: This reminder is provided to call the system installer's attention that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

21 Protective Attachment Plug - The product is equipped with an attachment plug having overload protection. This is safety feature. See Instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.

INTRODUCTION

Thank you for purchasing this 4 CHANNEL FM WIRELESS INTERCOM Model WI-4C.

This one is designed by P. L. L (Phase Locked Loop) communication system and hi-fidelity.

Also it's hi-sensitivity by use condenser microphone as transmit system. It's FM (Frequency Modulation) and operated without annoying interference and line noises.

All the safety and operating instruction should be read before the appliance is operated and retained for future reference.

CAUTIONS

Please reference following conditions when uses this items.

- The appliance should not be used near water. For example near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.
- The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliance(including amplifiers) that produce heat.
- Please avoid for use this item's at low temperature.
- It will be caused of falling-off a quality when uses this item's in the dust with mute.
- It will be caused of non-operate when uses this item's in a shutting place with direct ray of light.
- Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
- Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
- The power cord to the appliance should be unplugged from the outlet when left unused for a long period of time.